

Webb-Lok End Tip Replacement

- Step 1: Remove top screw and plastic spacer from track.
- Step 2: Pull shade and end tips out of the track.
- Step 3: Unscrew each end tip from rod mechanism
- Step 4: Screw new end tips onto rod mechanism
- Step 5: Adjust end tips to center shade in opening. A good rule of thumb is to pinch the finger clips together and center them on the shade. With the finger clips pinched and centered, adjust the end tip so that the edge where the aluminum and plastic meet on the end tip is even with the outside edge of the shade fabric.
- Step 6: Place end tips and shade back into the track.
- Step 7: Replace top screw and spacer into track



For installation information
www.youtube.com/webbshade